


TIKKA® XP 2

(EN) Tilttable head / (FR) Lampe orientable



(EN) Optical system / (FR) Système optique



(EN) Whistle / (FR) Sifflet



(EN) Battery installation / (FR) Installation des piles

Open / Ouvrir




Close / Fermer


Clic!




Battery / Piles



**WARNING!
RESPECT
POLARITY**



(EN) Battery discharge indicator / (FR) Témoin de décharge des piles




* maximum level

(EN) Lighting modes / (FR) Modes d'éclairage



On / Off



White lighting

1 Clic




2 Clics



3 Clics



Maximum




Economic



Flashing mode

**Long pressure
+ 2 s.**



Red lighting

1 Clic



2 Clics



Constant red



Flashing mode